

## Assembly instructions – Moulded backless bench

Tools: you will need a powerdriver with a PZ2 countersunk screw bit

Components:

1No, Bench top

2No, End support mouldings

12No, 90mm long countersunk stainless screws

4No, 70mm long countersunk stainless screws

- Place the bench top onto the ground with the framework uppermost
- Place the **narrow end** of the support mouldings against the inner frame (approximately 260mm from the bench end)
- Screw through the inside of the framework into the end support frames using 2No, 90mm long screws
- Repeat for the other end
- Flip the bench over
- From the bench top fit the remaining screws – **important the outer 4 holes use 70mm long screws and the 8 inner holes use 90mm long screws**

