

INSTALLATION INSTRUCTIONS RANGER TRI-TABLE

DOC REF: 416 ISSUE 01

ASSEMBLING THE TRI-TABLE
Place the table top on the packaging material (see inset) and assemble the support frames to the table using 6no. M12 x 100 coach bolts, washers, half nuts and shear nuts (see Step 6 / FIG. 1). Turn the table over and position it levelling the ground as necessary. IF THE SEATS ARE NOT TO BE ANCHORED GO TO STEP 6 (FIGURE2).

1

Always check for buried services

2

ANCHORING
Ensuring the Tri-Table is level insert the anchors into the support frames

3

ANCHORING
Put the drive extension into the anchor. Insert the **short end** of the ramrod into the drive extension, anchor and support frame.

4

Lift and ram down the ramrod until the anchor collar meets the support frame.
Repeat the operation for the other anchors. Check that the Tri-Table is level.

5

DRIVING OUT THE FLUKES
Withdraw the ramrod and insert the **long end**. Lift and ram down the ramrod to drive out the flukes. Repeat for the other anchors.

6

FIG. 1
TABLE
1/2 NUT
SHEARNUT
WASHERS
FRAME TUBE
COACHBOLT M12 x 100

FIG. 2
SEAT
1/2 NUT
WASHERS
SHEARNUT
FRAME BLOCK
FRAME UPRIGHT
COACHBOLT M12 x 100

FINAL ASSEMBLY OF THE TRI-TABLE
Attach the seats using the M12 x 190 coachbolts, washers, halfnuts and shearnuts (see Figure 2). Place the washer and halfnut onto the coachbolt in the order shown. Check the seats are level then tighten the halfnut. Place the second washer and shearnut, tighten and shear off the hexagonal head.
Caution: Shearing of the nuts can usually be sensed but we advise the wearing of gloves during tightening of nuts to prevent possible skinning of knuckles.